


GB



***PKB*TM 250**
***PKB*TM 400**



Instruction manual

0154 117 201 GB 20110711



DECLARATION OF CONFORMITY

According to

The Low Voltage Directive 2006/95/EC, entering into force 16 January 2007

Type of equipment

Welding Torches for MIG and MAG welding

Type designation etc.

PKB 250 and PKB 400 from serial number 933 xxx xxxx (2009 w.33)

Brand name or trade mark

ESAB

Manufacturer or his authorised representative established within the EEA

Name, address, telephone No, telefax No:

ESAB AB

Esabvägen, SE-695 81 LAXÅ, Sweden

Phone: +46 584 81 000, Fax: +46 584 411 924

The following harmonised standard in force within the EEA has been used in the design:

EN 60974-7, Arc welding equipment – Part 7: Torches

Additional information: Restrictive use. Welding torches are used with Class A equipment, intended for use in locations other than residential

By signing this document, the undersigned declares as manufacturer, or the manufacturer's authorised representative established within the EEA, that the equipment in question complies with the safety requirements stated above.

Date
Laxå 2011-07-11

Signature

Position
Manage Director
ESAB AB

A handwritten signature in blue ink, appearing to read "Håkan Führ".

Equipment and Automation
Håkan Führ
Clarification

1 SAFETY	3
2 INTRODUCTION	4
3 TECHNICAL DATA	4
4 INSTALLATION	5
4.1 Connecting the welding hose	5
5 OPERATION	6
6 MAINTENANCE	6
6.1 Daily or as necessary	6
6.2 Replacing the air filter	7
6.3 Replacing the wire guide	7
6.4 Dismantling the motor	8
6.5 Mounting the motor	9
7 TROUBLE SHOOTING	10
7.1 Checking for air leaks	10
8 ORDERING OF SPARE PARTS	10
9 DISASSEMBLY AND DISPOSAL	10
ORDERING NUMBER	11
WEAR PARTS	12
ACCESSORIES	16

1 SAFETY

ESAB can provide you with all necessary welding protection and accessories.



WARNING



Arc welding and cutting can be injurious to yourself and others. Take precautions when welding and cutting. Ask for your employer's safety practices which should be based on manufacturers' hazard data.

ELECTRIC SHOCK - Can kill

- Install and earth the unit in accordance with applicable standards.
- Do not touch live electrical parts or electrodes with bare skin, wet gloves or wet clothing.
- Insulate yourself from earth and the workpiece.
- Ensure your working stance is safe.

FUMES AND GASES - Can be dangerous to health

- Keep your head out of the fumes.
- Use ventilation, extraction at the arc, or both, to take fumes and gases away from your breathing zone and the general area.

ARC RAYS - Can injure eyes and burn skin.

- Protect your eyes and body. Use the correct welding screen and filter lens and wear protective clothing.
- Protect bystanders with suitable screens or curtains.

FIRE HAZARD

- Sparks (spatter) can cause fire. Make sure therefore that there are no inflammable materials nearby.

NOISE - Excessive noise can damage hearing

- Protect your ears. Use earmuffs or other hearing protection.
- Warn bystanders of the risk.

MALFUNCTION - Call for expert assistance in the event of malfunction.


Read and understand the instruction manual before installing or operating.

PROTECT YOURSELF AND OTHERS!



CAUTION

Read and understand the instruction manual before installing or operating.





CAUTION

This product is solely intended for arc welding.

2 INTRODUCTION

PKB is an air-operated welding gun with a pneumatic motor incorporated in the handle. A wire feed unit is fitted in the gun housing.

Different welding speeds can be selected by way of a valve regulating the speed of the motor.

The welding gun is available in two models, PKB 250 and PKB 400. In the PKB 400 model the outgoing air is used for forced cooling of the gun.

Swan Neck

The gun can be provided with a swan neck which is turnable 360° when the locking screws in the wire feed unit have been loosened.

The swan neck provides better access when welding in narrow spaces.

Gun Trigger

When the trigger is pressed into its first position the flow relay of the feed unit is activated and the operating circuit closes.

When the trigger is pressed as far as it will go the air valve is fully opened and the wire is fed according to the set value.

By slackening the trigger a little during welding, both the wire feed speed and the welding current will be decreased and the control of the molten pool will be improved.

Valve for Setting the Wire Feed Speed

The wire feed speed is proportional to the welding current and is set by way of the speed regulator on the welding gun.

The wire diameter is of vital importance to the welding current. The coarser the wire, the higher the amperage.

The speed regulator on the PKB is graded 0-9. The index arrow on the left-hand side of the gun housing indicates the zero position. The knob can be turned some 2.5 turns.

PKB 400 is provided with a hand shield against the heat radiation.

Welding Hose

The welding hose is available in three lengths: 5, 10 and 16 m.

3 TECHNICAL DATA

Welding gun	PKB 250	PKB 400
Permissible load at 60% duty cycle Carbon acid CO ₂ Gas mixture, Argon (Al electrode)	250 A / 26.5 V 200 A / 24 V	400 A / 34 V 280 A / 28 V
Electrode diameter	0.8-1.2 mm	0.8-1.6 mm
Air consumption	Max. 280 l/min	Max. 280 l/min
Air pressure, max	590 kPa (6 kp/cm ²)	590 kPa (6 kp/cm ²)
Dimensions l x h	210 x 250 mm	210 x 260 mm
Weight	1.2 kg	1.4 kg


Welding hose	A9-250	A9-400
Permissible load at 60% duty cycle Length: 5 m, 10 m, 16 m	250 A	400 A
Electrode diameter	0.8-1.2 mm	0.8-1.6 mm
Working pressure	490 kPa (5 kp/cm ²)	490 kPa (5 kp/cm ²)
Max. testing pressure	735 kPa (5 kp/cm ²)	735 kPa (5 kp/cm ²)

NB. Make sure the gun motor has the proper working pressure, 490 kPa (5 kp/cm²). If the pressure is lower the motor will not get the right speed, resulting in too low wire feed speed and welding current. If the pressure is higher the welding hose will be exposed to harmful dynamic pressure.

4 INSTALLATION

The installation must be carried out by a professional.

4.1 Connecting the welding hose



- Press the inlet nozzle (a), - selected according to the diameter of the wire - into the welding hose.
- Open the wire feed unit on the bobbin side.
- Undo the locking screw (b) on the connecting plate.
- Connect the welding hose (c) to the wire feed unit and tighten the locking screw on the connecting plate.
- Remove the plastic cover (d) from the gun housing.
- Undo the locking screw (e) and press the other end of the hose into the gun.
- Tighten the locking screw and fit the plastic cover.

5 OPERATION

General safety regulations for handling of the equipment can be found on page 4. Read through before you start using the equipment!

Welding Gun PKB 250 and PKB 400

Before starting to use of a new welding gun, or after replacement of the motor, the gun is to be operated at full air pressure for a short while.

This causes solidified oil and grease in the pneumatic motor to be dissolved, and ensures uninterrupted service.

6 MAINTENANCE




CAUTION

All guarantee undertakings from the supplier cease to apply if the customer attempts any work in the product during the guarantee period in order to rectify any faults.

6.1 Daily or as necessary

Nozzles


- Remove the gas nozzle.
- Clean the gas nozzle, the intermediate nozzle and the contact nozzle of welding spatter so that the shielding gas can flow freely and the risk of short-circuiting is eliminated.
- Check the gas nozzle for damage and wear. Replace the nozzle if damaged or worn.
- Select a contact nozzle according to the diameter of the wire.
- Assemble the parts.
- Spray with welding spray obliquely into the gas nozzle from two directions.
- **NB.** Never spray straight into the nozzle.



Pneumatic Motor

The motor is provided with an oil nipple for its lubrication.

- Lubricate the motor once a week (normal operation) using the lubrication gun supplied with the welding gun.
- Use oil, see accessories, page 19.



Feed Unit

- Take out and clean the feed unit of the gun as necessary.
- Lubricate the feed unit with some drops of oil.

6.2 Replacing the air filter


In order to protect the pneumatic motor of the welding gun from impurities the PKB guns are provided with an air filter.

The filter is fitted in the gun housing in the groove between the two O-rings where the gas hose is connected.

When a new filter is to be fitted the outer ring must first be removed.

- Make sure the filter is properly fixed before the O-ring is fitted.


6.3 Replacing the wire guide



<i>a</i>	<i>Inlet nozzle</i>	<i>f</i>	<i>Shielding gas inlet</i>
<i>b</i>	<i>Compression gland</i>	<i>g</i>	<i>Compressed-air inlet</i>
<i>c</i>	<i>Wire guide</i>	<i>h</i>	<i>O-rings (inside the tube)</i>
<i>d</i>	<i>O-rings</i>	<i>i</i>	<i>Outlet nozzle</i>
<i>e</i>	<i>Inlet end</i>		

- Undo the locking screws on the welding hose connections to the wire feed unit and the gun, then pull out the welding hose.
- Pull out the inlet nozzle (**a**) and screw out the compression gland (**b**) on the inlet side and the outlet nozzle (**i**) on the gun side.
- Withdraw the wire guide (**c**) from the inlet end. Make sure the o-rings (**d**) in the connecting piece come along.
- Fit the new wire guide. Stretch out the welding hose and check that the o-rings at the end of the gun are properly fitted in the grooves. Taper the end of the wire guide using a file.
- Insert the new guide through the gun connection. If this proves troublesome, lubricate the end of the wire guide with a little oil or silicon grease.
- Fasten the inlet nozzle (**i**) with screws at the gun end of the welding hose.
- Adjust the length of the guide (**c**) at the inlet end (**e**) of the welding hose. Cut the guide so as to include an excess length of six mm per metre hose, e.g. for a five-metre welding hose the wire guide is to be cut 30 mm outside the inlet end of the hose.
- Insert the o-rings round the wire guide and then fasten the compression gland (**b**) with screws.
- Press in the inlet nozzle (**a**).

6.4 Dismantling the motor




1. Remove the plastic cover (a) on the gun housing. Undo the locking screw (b) using an Allen key and remove the welding hose. Unload the spring (c) and undo the screws (d) holding the contact tube. Remove the tube.
2. Turn the welding gun upside-down. Wire the feed unit (e) can now be easily removed.
3. Insert a 90 mm long metal rod with a diameter of 2 mm through the hose connection hole in the gun housing. Push out the roll pin (f) in the motor shaft which holds the feed roller of the motor shaft in place. Remove the feed roller.

4. Remove the hand shield, if any, then gun trigger (m), rubber handle (n) and contact tube (h).
Check that the three o-rings of the tube (g) come along.
5. Fasten the motor housing (k), in a screw vice or the like, protected by two wooden jaws, and tighten moderately.
Screw out the left-threaded gun housing (l).

If the motor is rotating in its housing it cannot be dismantled from the housing of the gun. Then tighten the right-threaded rear (m) a bit harder, using an open end wrench with a jaw width of 28 mm.

6. Screw out the gun housing (l).
At the same time remove the protective cap (n) of the gasket ring (a transparent plastic sleeve) from the motor shaft.
Make sure that the sleeve, which is to be put back on the motor shaft, is not damaged.


6.5 Mounting the motor



1. Place the new motor (k) between the wooden jaws and tighten moderately.
Tighten the rear (m) and provide the motor shaft with a guide sleeve (o) to protect the gasket ring of the gun housing during the assembly.
Screw the left-threaded gun housing in place.

2. Loosen the right-threaded rear (m) using an open end wrench with a jaw width of 28 mm.
Now the gun housing (l) can be turned. Only the motor shaft is moving. The motor housing is secured by screws.
Turn the gun housing so that the rear, after having been tightened, gets into the proper position for fitting the connection tube.

3. Fit the connection tube (h), the rubber handle (j), the trigger (i), the protective cap (n) of the gasket ring, the feed roller (p) of the motor shaft and the wire feed unit (q).



The connection tube (h) and the three o-rings (g) are to be fitted very snugly.
Cement the rubber handle using Bostik 292 or the like.

7 TROUBLE SHOOTING

7.1 Checking for air leaks

During the test the device is to be run without electrode and shielding gas.

Test 1

- Turn on the compressed air to the max. pressure of 490 kPa (5 kp/cm²).
- Submerge the lower part of the gun handle into a container with methylated spirits.

Smaller leaks in the form of occasional air bubbles need not be attended to.

Test 2

- Hold the welding gun in such a way that the motor is in vertical position with the feed unit turned up.
- Pour methylated spirits on the bottom of the gun housing till the feed unit is covered.
- Push the gun trigger checking the gasket ring for air leaks.

After the Test

- Pour away the methylated spirits.
- Dry and clean the gun using compressed air.


8 ORDERING OF SPARE PARTS

PKB 250, PKB 400 is designed and tested in accordance with the international and European standards EN60974-7 and EN . It is the obligation of the service unit which has carried out the service or repair work to make sure that the product still conforms to the said standard.

Repair and electrical work should be performed by an authorized ESAB serviceman. Use only ESAB original spare and wear parts.

Spare parts may be ordered through your nearest ESAB dealer, see the last page of this publication.

9 DISASSEMBLY AND DISPOSAL



Dispose of electronic equipment at the recycling facility!


In observance of European Directive 2002/96/EC on Waste Electrical and Electronic Equipment and its implementation in accordance with national law, electrical and/or electronic equipment that has reached the end of its life must be disposed of at a recycling facility.

As the person responsible for the equipment, it is your responsibility to obtain information on approved collection stations.

For further information contact the nearest ESAB dealer.

The welding torch system is mainly made from steel, plastics and non-ferrous metal and must be disposed of in compliance with local environmental regulations. The disposal of coolant is also subject to local requirements.

Ordering number




Ordering numbers for PKB™ 250 and PKB™ 400

Ordering no.	Denomination	Type	Notes
0152 700 881	Welding gun	PKB™ 250	Straight swanneck
0152 470 881	Welding gun	PKB™ 400	Straight swanneck
0152 470 882	Welding gun	PKB™ 400	Curved swanneck
0157 117 990	Spare parts list		


Instruction manuals and the spare parts list are available on the Internet at www.esab.com

Wear parts

Item	Ordering no.	Denomination	Notes
	0152 700 881	PKB 250 complete push-pull gun	
1	0460 101 880	Feed roll driving	
2	0455 588 001	Valve complete	Soft start
3	0458 464 882	Gas nozzle, std	Straight/Curved swanneck
4	0458 471 003	Spatter protection	Straight/Curved swanneck
5	See wear parts	Contact tip	Straight/Curved swanneck
6	0366 394 001	Tip adapter	Straight/Curved swanneck
7	0468 221 001	Wearing tube	Straight swanneck
	0468 221 002	Wearing tube	Curved swanneck
8	0333 227 001	Guide nozzle	Straight/Curved swanneck




Item	Ordering no.	Denomination	Notes
	0152 470 881	PKB 400 complete push-pull gun	
1	0460 101 880	Feed roll driving	
2	0455 588 001	Valve complete	Soft start
3	0458 464 883	Gas nozzle, std	Straight/Curved swanneck
4	0458 471 004	Spatter protection	Straight/Curved swanneck
5	See wear parts	Contact tip	Straight/Curved swanneck
6	0366 394 002	Tip adapter	Straight/Curved swanneck
7	0468 221 003	Wearing tube	Straight swanneck,
	0468 221 004	Wearing tube	Curved swanneck
8	0333 227 001	Guide nozzle	Straight/Curved swanneck



Contact tip


Wire diameter	Standard-Welding with CO ₂ as shielding gas		Welding with gas mixture (Ar)	
	PKB 250	PKB 400	PKB 250	PKB 400
0.8 mm	0468 500 003	0468 502 003	0468 500 004	0468 502 004
0.9 mm	0468 500 004	0468 502 004	0468 500 005	0468 502 005
1.0 mm	0468 500 005	0468 502 005	0468 500 006	0468 502 006
1.2 mm	0468 500 006	0468 502 006	0468 500 007	0468 502 007
1.4 mm	-	0468 502 008	-	0468 502 009
1.6 mm	-	0468 502 009	-	0468 502 010

Item	Ordering no.	Denomination
1	0458 474 001	Compressed air motor complete
	0152 475 023	Lamellae
	0671 126 081	Feed mechanism complete
2	0460 104 880	Feed roller




Wire feed conduit

Item	Ordering no.		Denomination	Notes
	A9-250	A9-400		
1	0671 311 601	0671 311 601	Wire feed conduit	L= 5 m
	0671 311 606	0671 311 606	Wire feed conduit	L= 10 m
	0671 311 617	0671 311 617	Wire feed conduit	L= 16 m
2	0258 002 803	0258 002 803	Outlet nozzle	
3	0258 005 581	0258 005 581	Inlet nozzle	Ø 0.8 mm
	0258 002 582	0258 002 582	Inlet nozzle	Ø 1.0 mm
	0258 002 583	0258 002 583	Inlet nozzle	Ø 1.2 mm
	0258 002 584	0258 002 584	Inlet nozzle	Ø 1.6 mm




Accessories

Item	Ordering no.	Denomination	Notes
	0152 700 881	PKB 250 complete	
1	0152 475 025	Valve complete	Direct start
2	0693 201 201	Grease injector	
3	0151 370 001	Plastic oil capsule	
4	0367 581 881	Swanneck complete	Ø 9 mm Curved swanneck
	0368 002 883	Swanneck complete	Ø 9 mm Straight swanneck
5	0458 465 882	Gas nozzle, conical	Ø 13 mm Straight/Curved swanneck
6	0458 470 882	Gas nozzle, straight	Ø 18 mm Straight/Curved swanneck
7	0368 311 001	Tip adapter	HELIX Straight/Curved swanneck
8	0368 643 003	Spiral	(for hollow wire) Straight swanneck
	0368 643 001	Spiral	(for hollow wire) Curved swanneck




Item	Ordering no.	Denomination	Notes
	0152 470 881	PKB 400 complete	
1	0152 475 025	Valve complete	Direct start
2	0693 201 201	Grease injector	
3	0151 370 001	Plastic oil capsule	
4	0367 582 880	Swanneck complete	Ø 9 mm Curved swanneck
	0368 002 881	Swanneck complete	Ø 9 mm Straight swanneck
5	0458 465 883	Gas nozzle, conical	Ø 14 mm Straight/Curved swanneck
6	0458 470 883	Gas nozzle, straight	Ø 19 mm Straight/Curved swanneck
7	0368 311 001	Tip adapter	HELIX Straight/Curved swanneck
8	0368 643 004	Spiral	(for hollow wire) Straight swanneck
	0368 643 002	Spiral	(for hollow wire) Curved swanneck



Contact tip

Wire diameter	HELIX
	PKB 250/400
0.8 mm	0368 313 881
0.9 mm	0368 313 882
1.0 mm	0368 313 883
1.2 mm	0368 313 884
1.4 mm	0368 313 885
1.6 mm	0368 313 886

Lubricant	Ordering number
Shell Super Oil 10 W/50	0151 370 001



ESAB subsidiaries and representative offices

Europe

AUSTRIA

ESAB Ges.m.b.H
Vienna-Liesing
Tel: +43 1 888 25 11
Fax: +43 1 888 25 11 85

BELGIUM

S.A. ESAB N.V.
Brussels
Tel: +32 2 745 11 00
Fax: +32 2 745 11 28

BULGARIA

ESAB Kft Representative Office
Sofia
Tel/Fax: +359 2 974 42 88

THE CZECH REPUBLIC

ESAB VAMBERK s.r.o.
Vamberk
Tel: +420 2 819 40 885
Fax: +420 2 819 40 120

DENMARK

Aktieselskabet ESAB
Herlev
Tel: +45 36 30 01 11
Fax: +45 36 30 40 03

FINLAND

ESAB Oy
Helsinki
Tel: +358 9 547 761
Fax: +358 9 547 77 71

FRANCE

ESAB France S.A.
Cergy Pontoise
Tel: +33 1 30 75 55 00
Fax: +33 1 30 75 55 24

GERMANY

ESAB GmbH
Solingen
Tel: +49 212 298 0
Fax: +49 212 298 218

GREAT BRITAIN

ESAB Group (UK) Ltd
Waltham Cross
Tel: +44 1992 76 85 15
Fax: +44 1992 71 58 03

ESAB Automation Ltd
Andover
Tel: +44 1264 33 22 33
Fax: +44 1264 33 20 74

HUNGARY

ESAB Kft
Budapest
Tel: +36 1 20 44 182
Fax: +36 1 20 44 186

ITALY

ESAB Saldatura S.p.A.
Bareggio (Mi)
Tel: +39 02 97 96 8.1
Fax: +39 02 97 96 87 01

THE NETHERLANDS

ESAB Nederland B.V.
Amersfoort
Tel: +31 33 422 35 55
Fax: +31 33 422 35 44

NORWAY

AS ESAB
Larvik
Tel: +47 33 12 10 00
Fax: +47 33 11 52 03

POLAND

ESAB Sp.zo.o.
Katowice
Tel: +48 32 351 11 00
Fax: +48 32 351 11 20

PORTUGAL

ESAB Lda
Lisbon
Tel: +351 8 310 960
Fax: +351 1 859 1277

ROMANIA

ESAB Romania Trading SRL
Bucharest
Tel: +40 316 900 600
Fax: +40 316 900 601

RUSSIA

LLC ESAB
Moscow
Tel: +7 (495) 663 20 08
Fax: +7 (495) 663 20 09

SLOVAKIA

ESAB Slovakia s.r.o.
Bratislava
Tel: +421 7 44 88 24 26
Fax: +421 7 44 88 87 41

SPAIN

ESAB Ibérica S.A.
Alcalá de Henares (MADRID)
Tel: +34 91 878 3600
Fax: +34 91 802 3461

SWEDEN

ESAB Sverige AB
Gothenburg
Tel: +46 31 50 95 00
Fax: +46 31 50 92 22

ESAB international AB
Gothenburg

Tel: +46 31 50 90 00
Fax: +46 31 50 93 60

SWITZERLAND

ESAB AG
Dietikon
Tel: +41 1 741 25 25
Fax: +41 1 740 30 55

UKRAINE

ESAB Ukraine LLC
Kiev
Tel: +38 (044) 501 23 24
Fax: +38 (044) 575 21 88

North and South America

ARGENTINA

CONARCO
Buenos Aires
Tel: +54 11 4 753 4039
Fax: +54 11 4 753 6313

BRAZIL

ESAB S.A.
Contagem-MG
Tel: +55 31 2191 4333
Fax: +55 31 2191 4440

CANADA

ESAB Group Canada Inc.
Mississauga, Ontario
Tel: +1 905 670 02 20
Fax: +1 905 670 48 79

MEXICO

ESAB Mexico S.A.
Monterrey
Tel: +52 8 350 5959
Fax: +52 8 350 7554

USA

ESAB Welding & Cutting Products
Florence, SC
Tel: +1 843 669 44 11
Fax: +1 843 664 57 48

Asia/Pacific

CHINA

Shanghai ESAB A/P
Shanghai
Tel: +86 21 2326 3000
Fax: +86 21 6566 6622

INDIA

ESAB India Ltd
Calcutta
Tel: +91 33 478 45 17
Fax: +91 33 468 18 80

INDONESIA

P.T. ESABindo Pratama
Jakarta
Tel: +62 21 460 0188
Fax: +62 21 461 2929

JAPAN

ESAB Japan
Tokyo
Tel: +81 45 670 7073
Fax: +81 45 670 7001

MALAYSIA

ESAB (Malaysia) Snd Bhd
USJ
Tel: +603 8023 7835
Fax: +603 8023 0225

SINGAPORE

ESAB Asia/Pacific Pte Ltd
Singapore
Tel: +65 6861 43 22
Fax: +65 6861 31 95

SOUTH KOREA

ESAB SeAH Corporation
Kyungnam
Tel: +82 55 269 8170
Fax: +82 55 289 8864

UNITED ARAB EMIRATES

ESAB Middle East FZE
Dubai
Tel: +971 4 887 21 11
Fax: +971 4 887 22 63

Africa

EGYPT

ESAB Egypt
Dokki-Cairo
Tel: +20 2 390 96 69
Fax: +20 2 393 32 13

SOUTH AFRICA

ESAB Africa Welding & Cutting Ltd
Durbanvill 7570 - Cape Town
Tel: +27 (0)21 975 8924

Distributors

For addresses and phone numbers to our distributors in other countries, please visit our home page

www.esab.com



www.esab.com

